TroubleShooting Guide Electrical System



Checking the Mower

TASK	INSTRUCTIONS	NOTES
Inspect Electrical Circuit	 With the motor off: Unplug the clutch and attach a voltage meter to the connection Coming from the mower. Start the mower 	PTO ON = Voltage is 13.2 DC Minimum PTO OFF = Voltage is 0.0 DC
	and Turn the PTO on (blade engage switch) — Monitor the meter: 13.2vlt to 14vlt DC is normal. Turn the PTO off: 0.0 vlt is perfect.	With the PTO switch in the on position the voltage should be between 13.2 & 14VDC If the voltage is different there is a problem with the mowers' electrical system.
Inspect Electrical Connections	- Remove the wire harness connector(s) Inspect and Clean each connection going to the clutch.	
Inspect Wire Harness	 Remove the tie wraps from the wire harness = Look for pinching, chaffing, fraying or tares Check the machine wire harness for damage. 	Look closely: This is a common failure

Checking the Clutch

	TASK	INSTRUCTIONS	NOTES
Checking th	e Clutch Coil ations)	 Apply 12vlt DC to the clutch connection & - watch to see if the coil draws the armature to the rotor (pulls the pulley inward) 	Some low torque clutches may not be able to overcome the clutch brake and will require resistance testing.
Checking Cl	utch Resistance	 Connect a Low Resistance (ohm) meter to the clutch wire connector. Compare the results to the chart below. 	A Special "4 wire" Low Resistance (Ohms) Meter is required. Normal voltage/ohms meters cannot read ohms this low.
	MODEL	TORQUE	RESISTANCE @70 F (Ohms)
MS-60 MS-80	(5217-***) (5217-***)	60 ft. lbs (81Nm) Torque 80 ft. lbs (108Nm) Torque	6.82 to 7.54 Ohms 3.49 to 3.86 Ohms
TG2K-125	(5219-***)	125 ft. lbs (169Nm) Torque	2.70 to 2.98 Ohms
CMS-150	(5218-***)	150 ft. lbs (203Nm) Torque	2.34 to 2.59 Ohms
CMS-175	(5218-***)	175 ft. lbs (237Nm) Torque	2.18 to 2.41 Ohms
CMS-200	(5218-***)	200 ft. lbs (271Nm) Torque	1.75 to 2.00 Ohms